

# Supplement

Title: 360 Instruction Sheet

Supplement Issue: 1

Part Number: 2726405

Issue Date: 6/08

Print Date: October 2006

Page Count: 2

Revision/Date:

---

---

This supplement contains information necessary to ensure the accuracy of the above Instruction Sheet.

## Change #1, 47119

Under ***Auto Power Off***, add the following Paragraph:

Press mA/A or HOLD button to postpone automatic power off for another 10 minutes. To disable auto power off, press the hold button and power button when turning on clamp meter. After approximately 3 seconds, the auto off indicator will turn off. The clamp meter will default to auto off enabled at power on.

Under ***General Specifications***, replace the ***Temperature Coefficient*** section with the following:

**Temperature Coefficient** <18 °C or >28 °C

Measuring range: 0 to 50 A  
 $\pm 0.08$  % of reading/°C + 0.5  
digit

Measuring range: 50 to 60 A  
 $\pm 0.3$  % of reading/°C  $\pm 0.5$   
digit

Under ***Electrical Specifications***, add:

**Frequency:** 50 Hz  $\pm 1$  Hz, 60 Hz  $\pm 1$  Hz